

PRESSMAX

XtraMax Revival Gel R71

DEGLAZER GEL TO REMOVE CALCIUM DEPOSITS FROM ROLLER AND
BLANKETS

Key Characteristics

- ✓ For rollers and blankets
- ✓ Water miscible
- ✓ Manual use
- ✓ Cleaning gel

Directions for use

Blankets:

Apply by moistening a cleaning cloth well with it and rub the blanket vigorously.

Ink rollers:

Clean the ink rollers first with a conventional wash. Then apply evenly on the rollers and let it run up to 5 minutes, depending on the contamination. Make sure that the ink duct unit is separated from the ink rollers. Remove with water from the ink rollers.

Transport and storage

Protect against extreme weather conditions. Do not store at temperature above 35 °C or below -10 °C. Take necessary precautions to avoid environment pollution due to accidental leakage.

Packaging

- 10 x 500 g tubes

Features and benefits

Cleaning gel

- ✓ Easy to apply

Strong cleaning power

- ✓ Removes fast and easily calcium deposits

FUJIFILM